



# **Digital Signal Processing** **Laboratory**

## **EXPERIMENT-8**

***Shorya Sharma***  
***19EE01017***

# To perform IIR Filter Design Using Pole-Zero Placement Method

## Theory:

In this experiment, we study the design of simple digital filters using pole-zero placement method.

$$H(\omega) = \frac{B(\omega)}{A(\omega)} = \frac{\sum_{k=0}^M b_k e^{-j\omega k}}{1 + \sum_{k=1}^N a_k e^{-j\omega k}} = b_0 \frac{\prod_{k=1}^M (1 - z_k e^{-j\omega})}{\prod_{k=1}^N (1 - p_k e^{-j\omega})} \quad (1)$$

where  $b_0$  is a gain constant selected to normalize frequency response at some specified frequency that is computed such that  $|H(\omega_o)| = 1$

$$H(\omega) = b_0 \frac{\prod_{k=1}^M (1 - z_k z^{-1})}{\prod_{k=1}^N (1 - p_k z^{-1})} \quad (2)$$

or equivalently

$$H(\omega) = b_0 e^{j\omega(N-M)} \frac{\prod_{k=1}^M (e^{j\omega} - z_k)}{\prod_{k=1}^N (e^{j\omega} - p_k)} \quad (3)$$

From this expression,

- The presence of a zero close to the unit circle causes the magnitude of the frequency response to be small at frequencies that correspond to points of the unit circle to that point.
- The presence of a pole close to the unit circle causes the magnitude of the frequency response to be large at frequencies close to that point.
- Placing a zero close to a pole cancels the effect of the pole, and vice versa.
- The presence of both poles and zeros in the transfer function results in a greater variety of magnitude and phase response shapes

1. A first-order lowpass filter is required to satisfy the following specifications:

- Sampling rate:  $F_s = 360$  Hz
- 3 dB cutoff frequency:  $F_c = 40$  Hz
- Zero gain at 180 Hz

$$\text{Since } f_c < \frac{f_s}{4} \Rightarrow \alpha \approx 1 - 2\left(\frac{f_c}{f_s}\right)\pi \Rightarrow \alpha = 1 - 2\left(\frac{360}{40}\right)\pi = 0.3018$$

$$\Rightarrow K = \frac{(1 - \alpha)}{2} = \frac{(1 - 0.3018)}{2} = 0.991$$

### 1) Transfer Function

The Transfer function is given by  $H(z) = \frac{K(z+1)}{(z-\alpha)} \Rightarrow H(z) = \frac{0.991(z+1)}{(z-0.982)}$

*Enter your equation.*

### 2) Magnitude and Phase Response

#### Code:

```
clc;
close all;
clear variables;


w= -pi:0.001:pi;

%Sampling and cutoff Frequencies
fs=360;
fc=40;

zero = -1; %Zero at -1
al = 1-2*fc/fs*pi; %Alpha = Pole
K = (1-al)/2; %Gain


%Transfer Function
Hz=K*prod((exp(1i.*w)-zero),1)./prod((exp(1i.*w)-al),1);

figure(1);
subplot(2,1,1); plot(w.*fs./2./pi,abs(Hz));
xlabel('Frequency (Hz)\rightarrow');ylabel('Magnitude(dB)\rightarrow');
title('Magnitude Response of Ist order LPF');
subplot(2,1,2);plot(w.*fs./2./pi, angle(Hz));
xlabel('Frequency (Hz)\rightarrow');ylabel('Phase (in Radians)\rightarrow');
title('Phase Response of Ist order LPF');
```



### Pole Zero Plot

```
figure(2);  
zplane(zero,a1);  
title('Pole-Zero plot for First order LPF');
```




### 3.a) Output from filter with input ECG signal sampled at 360 Hz.

```
load('ecg_360_noise.mat');
x1 = ecg_0p10;

[b, a] = zp2tf(zero,a1,K); %converting zero-pole
y1 = filter(b, a, x1);

t1=(1:size(x1, 2))./ fs;
figure(3);
subplot(2,1,1);plot(t1, x1);
xlabel('Time\rightarrow');ylabel('Amplitude\rightarrow');
title('Original ECG Signal');
subplot(2,1,2);plot(t1, y1);
xlabel('Time\rightarrow');ylabel('Amplitude\rightarrow');
title('Low Pass Filtered ECG Signal');
```




### 3.b) Output from filter with input ECG with AWGN signal sampled at 360 Hz.

```
load('ecg_awgn_fs_360.mat');
x2 = ecg_awgn;

[b, a] = zp2tf(zero,a1,K); %converting zero-pole
y2 = filter(b, a, x2);

t2=(1:size(x2, 2))./ fs;
figure(4);
subplot(2,1,1);plot(t2, x2);
xlabel('Time\rightarrow');ylabel('Amplitude\rightarrow');
title('Original ECG with AWGN Signal');
subplot(2,1,2);plot( y2);
xlabel('Time\rightarrow');ylabel('Amplitude\rightarrow');
title('Low pass Filtered ECG Signal');
```



#### 4) Difference Equation

$$\Rightarrow \frac{Y(z)}{X(z)} = \frac{0.349(z+1)}{(z-0.3018)} \Rightarrow 0.349X(z) + 0.349X(z)z^{-1} = Y(z) - 0.3018Y(z)z^{-1}$$

Taking Inverse Z-transform ,  $y[n] - 0.3018y[n-1] = 0.349(x[n] + x[n-1])$

## 2. A first-order highpass filter is required to satisfy the following specifications:

- **Sampling rate:  $F_s = 360$  Hz**
- **3 dB cut-off frequency:  $F_c = 1$  Hz**
- **Zero gain at 0 Hz.**

$$\text{Since } f_c < \frac{f_s}{4} \Rightarrow \alpha \approx 1 - 2\left(\frac{f_c}{f_s}\right)\pi \Rightarrow \alpha = 1 - 2\left(\frac{1}{360}\right)\pi = 0.982$$

$$\Rightarrow K = \frac{(1 + \alpha)}{2} = \frac{(1 + 0.982)}{2} = 0.991$$

### 1) Transfer Function

$$\text{The Transfer function is given by } H(z) = \frac{K(z-1)}{(z-\alpha)} \Rightarrow H(z) = \frac{0.991(z-1)}{(z-0.982)}$$

### 2) Magnitude and Phase Response

#### Code:

```
clc;
close all;
clear variables;

w= -pi:0.001:pi;


%Sampling and cutoff Frequencies
fs=360;
fc=1;

zero = 1; %Zero at 1
al = 1-2*fc/fs*pi; %Alpha = Pole
K = (1+al)/2; %Gain

%Transfer Function
Hz=K*prod((exp(1i.*w)-zero),1)./prod((exp(1i.*w)-al),1);


figure(1);
subplot(2,1,1); plot(w.*fs./2./pi,abs(Hz));
xlabel('Frequency (Hz)\rightarrow');ylabel('Magnitude(dB)\rightarrow');
title('Magnitude Response of Ist order HPF');
subplot(2,1,2);plot(w.*fs./2./pi, angle(Hz));
xlabel('Frequency (Hz)\rightarrow');ylabel('Phase (in Radians)\rightarrow');
title('Phase Response of Ist order HPF');
```





### Pole Zero Plot

```
figure(2);  
zplane(zero,a1);  
title('Pole-Zero plot for First order HPF');
```




### 3.a) Output from filter with input ECG signal sampled at 360 Hz.

```
load('ecg_360_noise.mat');
x1 = ecg_0p10;

[b, a] = zp2tf(zero,a1,K); %converting zero-pole
y1 = filter(b, a, x1);

t1=(1:size(x1, 2))./ fs;
figure(3);
subplot(2,1,1);plot(t1, x1);
xlabel('Time\rightarrow');ylabel('Amplitude\rightarrow');
title('Original ECG Signal');
subplot(2,1,2);plot(t1, y1);
xlabel('Time\rightarrow');ylabel('Amplitude\rightarrow');
title('High Pass Filtered ECG Signal');
```




### 3.b) Output from filter with input ECG with AWGN signal sampled at 360 Hz.

```
load('ecg_awgn_fs_360.mat');
x2 = ecg_awgn;

[b, a] = zp2tf(zero,a1,K); %converting zero-pole
y2 = filter(b, a, x2);

t2=(1:size(x2, 2))./ fs;
figure(4);
subplot(2,1,1);plot(t2, x2);
xlabel('Time\rightarrow');ylabel('Amplitude\rightarrow');
title('Original ECG with AWGN Signal');
subplot(2,1,2);plot( y2);
xlabel('Time\rightarrow');ylabel('Amplitude\rightarrow');
title('High pass Filtered ECG Signal');
```



#### 4) Difference Equation

$$\Rightarrow \frac{Y(z)}{X(z)} = \frac{0.991(z+1)}{(z-0.982)} \Rightarrow 0.991X(z) - 0.991X(z)z^{-1} = Y(z) - 0.982Y(z)z^{-1}$$

Taking Inverse Z-transform ,  $y[n] - 0.982y[n-1] = 0.991(x[n] - x[n-1])$

3. A second-order bandpass filter is required to satisfy the following specifications:

- a. Sampling rate:  $F_s = 360$  Hz
- b. 3 dB bandwidth:  $BW = 14$  Hz
- c. Narrow passband centered at  $F_o = 13$  Hz
- d. Zero gain at 0 Hz and 180 Hz.

Since

$$r \approx 1 - \left( \frac{BW_{3dB}}{f_s} \right) \pi = 1 - \left( \frac{14}{360} \right) \pi = 0.8778$$

$$\theta = \frac{f_o}{f_s} \times 360^\circ = \frac{13}{360} \times 360^\circ = 13^\circ$$

$$\Rightarrow K = \frac{(1-r) \sqrt{1 - 2r \cos(2\theta) + r^2}}{2|\sin(\theta)|} = 0.991$$

### 1) Transfer Function

The Transfer function is given by  $H(z) = \frac{K(z-1)(z+1)}{(z-re^{j\theta})(z-re^{-j\theta})} = \frac{K(z-1)(z+1)}{(z^2 - 2rz\cos\theta + r^2)}$

$$\Rightarrow H(z) = \frac{0.119(z^2 - 1)}{z^2 - 1.71z + 0.77}$$

### 2) Magnitude and Phase Response

#### Code:

```
clc;
close all;
clear variables;

w= -pi:0.001:pi;


%Sampling,3dB Bandwidth and
% Passband centre Frequencies
fs=360;
BW = 14;
fo = 13;

r = 1 - (BW/fs)*pi;
theta = 2*pi*fo/fs;

zero = [-1,1];
p = [r*exp(1i*theta),r*exp(-1i*theta)];
K = (1-r)*sqrt(1-2*r*cos(2*theta)+r^2)/(2*abs(sin(theta)));


%Transfer Function
Hz=K*prod((exp(1i.*w)-zero'),1)./prod((exp(1i.*w)-p'),1);
```

```
figure(1);
subplot(2,1,1); plot(w.*fs./2./pi,abs(Hz));
xlabel('Frequency (Hz)\rightarrow');ylabel('Magnitude(dB)\rightarrow');
title('Magnitude Response of Ist order HPF');
subplot(2,1,2);plot(w.*fs./2./pi, angle(Hz));
xlabel('Frequency (Hz)\rightarrow');ylabel('Phase (in Radians)\rightarrow');
title('Phase Response of 2nd order BPF');
```



### Pole Zero Plot

```
figure(2);
zplane(zero',p');
title('Pole-Zero plot for 2nd Order BPF');
```




### 3.a) Output from filter with input ECG signal sampled at 360 Hz.

```
load('ecg_360_noise.mat');
x1 = ecg_0p10;

[b, a] = zp2tf(zero',p',K); %converting zero-pole
y1 = filter(b, a, x1);

t1=(1:size(x1, 2))./ fs;
figure(3);
subplot(2,1,1);plot(t1, x1);
xlabel('Time\rightarrow');ylabel('Amplitude\rightarrow');
title('Original ECG Signal');
subplot(2,1,2);plot(t1, y1);
xlabel('Time\rightarrow');ylabel('Amplitude\rightarrow');
title('Band Pass Filtered ECG Signal');
```




### 3.b) Output from filter with input ECG with AWGN signal sampled at 360 Hz.

```
load('ecg_awgn_fs_360.mat');
x2 = ecg_awgn;

[b, a] = zp2tf(zero',p',K); %converting zero-pole
y2 = filter(b, a, x2);

t2=(1:size(x2, 2))./ fs;
figure(4);
subplot(2,1,1);plot(t2, x2);
xlabel('Time\rightarrow');ylabel('Amplitude\rightarrow');
title('Original ECG with AWGN Signal');
subplot(2,1,2);plot( y2);
xlabel('Time\rightarrow');ylabel('Amplitude\rightarrow');
title('Band pass Filtered ECG Signal');
```





#### 4) Difference Equation

$$\Rightarrow \frac{Y(z)}{X(z)} = \frac{0.119(z^2 - 1)}{(z^2 - 1.71z + 0.77)} \Rightarrow 0.119X(z) - 0.119X(z)z^{-2} = Y(z) - 1.71Y(z)z^{-1} + 0.77Y(z)z^{-2}$$

Taking Inverse Z-transform ,  $y[n] - 1.71y[n - 1] + 0.77y[n - 2] = 0.119(x[n] - x[n - 2])$

4. A second-order notch filter is required to satisfy the following specifications:

- a. Sampling rate:  $F_s = 360$  Hz
- b. 3 dB bandwidth:  $BW = 4$  Hz
- c. Narrow passband centered at  $F_o = 50$  Hz

$$r \approx 1 - \left( \frac{BW_{3dB}}{f_s} \right) \pi = 1 - \left( \frac{4}{360} \right) \pi = 0.9651$$

Since

$$\theta = \frac{f_o}{f_s} \times 360^\circ = \frac{50}{360} \times 360^\circ = 50^\circ$$

$$\Rightarrow K = \frac{1 - 2r\cos(2\theta) + r^2}{2 - 2\cos(\theta)} = 0.9668$$

### 1) Transfer Function

The Transfer function is given by  $H(z) = \frac{K(z - e^{j\theta})(z - e^{-j\theta})}{(z - re^{j\theta})(z - re^{-j\theta})} = \frac{K(z^2 - 2z\cos\theta + 1)}{(z^2 - 2rz\cos\theta + r^2)}$

$$\Rightarrow H(z) = \frac{0.9668(z^2 - 1.28557z + 1)}{z^2 - 1.24z + 0.9314}$$

### 2) Magnitude and Phase Response

#### Code:

```
clc;
close all;
clear variables;

w= -pi:0.001:pi;


%Sampling,3dB Bandwidth and
% Passband centre Frequencies
fs=360;
BW = 4;
fo = 50;

r = 1 - (BW/fs)*pi;
theta = 2*pi*fo/fs;

zero=[exp(1i*theta),exp(-1i*theta)];
p = [r*exp(1i*theta),r*exp(-1i*theta)];
K = (1-(2*r*cos(theta))+(r*r))/(2-2*cos(theta));


%Transfer Function
Hz=K*prod((exp(1i.*w)-zero'),1)./prod((exp(1i.*w)-p'),1);
```

```
figure(1);
subplot(2,1,1); plot(w.*fs./2./pi,abs(Hz));
xlabel('Frequency (Hz)\rightarrow');ylabel('Magnitude(dB)\rightarrow');
title('Magnitude Response of 2nd order Notch Filter');
subplot(2,1,2);plot(w.*fs./2./pi, angle(Hz));
xlabel('Frequency (Hz)\rightarrow');ylabel('Phase (in Radians)\rightarrow');
title('Phase Response of 2nd order Notch Filter');
```



### Pole Zero Plot

```
figure(2);
zplane(zero',p');
title('Pole-Zero plot for 2nd order Notch Filter');
```




### 3.a) Output from filter with input ECG signal sampled at 360 Hz.

```
load('ecg_360_noise.mat');
x1 = ecg_0p10;

[b, a] = zp2tf(zero',p',K); %converting zero-pole
y1 = filter(b, a, x1);

t1=(1:size(x1, 2))./ fs;
figure(3);
subplot(2,1,1);plot(t1, x1);
xlabel('Time\rightarrow');ylabel('Amplitude\rightarrow');
title('Original ECG Signal');
subplot(2,1,2);plot(t1, y1);
xlabel('Time\rightarrow');ylabel('Amplitude\rightarrow');
title('Notch Filtered ECG Signal');
```




### 3.b) Output from filter with input ECG with AWGN signal sampled at 360 Hz.

```
load('ecg_awgn_fs_360.mat');
x2 = ecg_awgn;

[b, a] = zp2tf(zero',p',K); %converting zero-pole
y2 = filter(b, a, x2);

t2=(1:size(x2, 2))./ fs;
figure(4);
subplot(2,1,1);plot(t2, x2);
xlabel('Time\rightarrow');ylabel('Amplitude\rightarrow');
title('Original ECG with AWGN Signal');
subplot(2,1,2);plot( y2);
xlabel('Time\rightarrow');ylabel('Amplitude\rightarrow');
title('Notch Filtered ECG Signal');
```



#### 4) Difference Equation

$$\Rightarrow \frac{Y(z)}{X(z)} = \frac{0.991(z+1)}{(z-0.982)} \Rightarrow 0.9668X(z) - 1.242X(z)z^{-1} + 0.9668X(z)z^{-2} = Y(z) - 1.24Y(z)z^{-1} + 0.9314Y(z)z^{-2}$$

Taking Inverse Z-transform ,  $y[n] - 1.24y[n-1] + 0.9314y[n-2] = 0.9668(x[n] + x[n-2]) - 1.242x[n-1]$